



Ford Mondeo 2001 Ford Focus from 12/2000

Re-programming the radio remote control.

With these vehicles it is possible to change radio remote control functions. There are two possible functions of the unlocking button on the hand-held transmitter:

1. Pressing the unlocking button once = The double-locking and the alarm system (if fitted) are deactivated and all the doors are unlocked.
2. Pressing the unlocking button once = The double-locking and the alarm system are deactivated and only the driver's door is unlocked. Pressing the button a second time within 3 seconds unlocks all the doors.

In order to change between the two possibilities, proceed as follows:

- Switch the ignition off.
- Keep the locking und unlocking buttons pressed simultaneously for 4 seconds.
- The successful change will be indicated by the direction indicators flashing twice.

The re-programming can be changed again in the same way.