



Mercedes Benz E-Class (W 210) All models with ABS/BAS

ABS/BAS control lamp illuminates.

If there are complaints with these vehicles that after disconnecting and reconnecting the vehicle battery the ABS/BAS control lamp illuminates and does not switch off, one possible cause is the disconnection of the battery. Due to the missing voltage supply, stored data in the control unit is lost. In this case, no fault code is stored in the fault memory. A long test drive with different driving situations common in traffic can be used to allow the control unit to re-record the deleted data. If, after the test drive, the ignition is switched off and on again, the ABS/BAS control lamp should switch off.

Bulletin