



Peugeot 206

All models with a key without radio remote control

Vehicle does not start.

If there are complaints with these vehicles that the engine is turned over by the starter but does not start up, this could be caused by the immobilizer not being deactivated. With keys without radio remote control, the adhesion between the two halves of the key can dissolve and the transponder chip for deactivating the immobilizer can be lost.

Check the key to see whether the two halves of the housing are still glued together properly. If the adhesion has dissolved and the transponder chip is no longer in place, the fault can only be remedied by a new key. The new key must be adapted to the immobilizer according to the manufacturer's instructions.

Bulletin

