



Renault Megane I All models with petrol engine Model year from 1996

Engine does not start, airbag control lamp glows.

If there are complaints with these vehicles that the engine does not start and that the airbag control lamp glows, one possible cause is a blown fuse. Due to the blown fuse, the engine control (injection system/ignition system) fails and faults in the airbag system arise. It is not possible to take a readout of the fault memory of the engine and airbag control unit, either. In order to eliminate the fault, the fuses in the engine-bay fuse box must be tested and, if necessary, replaced. The fuse box may differ according to model year. As a rule, a 7.5 A fuse for the engine control and the airbag system is affected.

More detailed information on fuse assignment can be found in the operating instructions.

Bulletin

