



Opel

Omega B

Model year: up to 08.1996

With manual air conditioning system

Interior blower

1st level does not work

If with the above-mentioned vehicles the 2nd level of the interior blower switches on instead of the 1st level when the air conditioning system is switched on, this can be due to faulty wiring. It is then not possible to switch the blower down to the 1st level.

With the aid of the vehicle-specific and system-specific circuit diagram, the control of the blower motor can be changed in such a way that the 1st level of the blower is switched on when the air conditioning system is switched on. For this purpose, the wiring on the plug of the blower motor input resistor has to be changed accordingly. 2 relays are used to control the blower (1st and 4th blower level). Make sure that only the blue cable coming from the relay (1st level) is reconnected. The blue cable leading from the blower switch to the input resistor must not be reconnected.

Bulletin